

SUD Version 2 firmware upgrade light sequence

The version 2 firmware for the SUD is required to work with a [seneye web server](#) (SWS). The following light sequences are updated from the version 1 firmware.

Taking reading or communicating (power on).



Reading taken and alert switching on (temperature - all behave the same).



Alert on for temperature and a reading being taken.



Out of water!

