



Your SWS is designed to failsave in the event of a failure to update the firmware correctly. Whilst this is a very rare occurrence, it is designed to do this so the device can be easily recovered.

If your device is in bootload mode then the lights will be flashing in this sequence:



To recover your device from this state, please follow the instructions below:

Remove the seneye device from your SWS

Format a USB memory stick (ideally 8GB or smaller) to "FAT32"

*If you are using a MAC click [here](#) for instructions*

Download the SWS firmware from [here](#)

Copy the firmware onto the memory stick

Insert the stick into the USB socket on the SWS

*The light sequence will then change whilst the firmware is loading*



When the firmware is loaded the power light will remain on constantly

Reconnect any cables that you have disconnected