



Seneye is a USB product that is designed to work with your PC.

You can connect the SUD (Seneye USB Device) directly to your PC using the seneye connect application (SCA), or via a SWS.

The seneye web server (SWS) allows you to make any seneye device work more efficiently and effectively. It allows you to use a seneye without a PC and view the results directly from your smartphone, tablet, or computer.

There are two versions available, the [non-WiFi version](#) which can be used with an ethernet cable connected to your internet router, or the [WiFi version](#) which comes with a WiFi adaptor allowing you to connect to your wireless network.

To use the SWS outdoors, a [seneye Dri box](#) is the simplest way to connect up everything next to the pond.

[SWS overview](#)